



587 East Middle Turnpike, P.O. Box 370, Manchester, CT 06040  
Telephone: 860.645.1102 Fax: 860.645.0823

## **SAMPLING WATER FOR VOLATILES ANALYSIS**

Fill both bottles slowly until water bulges on tip of rim. Quickly place cap on vial. Turn vial upside down and tap cap firmly. Allow no airspace or bubbles.

If any bubbles are seen, do not empty vial- simply add more water. Again, check for air bubbles.

If you have any questions, give us a call!  
**860-645-1102**